

Rotary actuator for ball valves

- Torque motor 5 Nm
- Nominal voltage AC/DC 24 V
 Control Open/close, 3-point
- with integrated auxiliary switch



Technical data

Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage frequency	50/60 Hz
9.5	Nominal voltage range	AC 19.228.8 V / DC 19.228.8 V
	Power consumption in operation	1.5 W
	Power consumption in rest position	0.2 W
	Power consumption for wire sizing	2 VA
	Auxiliary switch	1x SPDT, 0100%
	Switching capacity auxiliary switch	1 mA3 A (0.5 A inductive), DC 5 VAC 250 V
	Connection supply / control	Cable 1 m, 3x 0.75 mm²
	Connection auxiliary switch	Cable 1 m, 3x 0.75 mm²
	Parallel operation	Yes (note the performance data)
Functional data	Torque motor	5 Nm
	Manual override	with push-button, can be locked
	Running time motor	90 s / 90°
	Sound power level, motor	35 dB(A)
	Position indication	Mechanical, pluggable
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
	Power source UL	Class 2 Supply
	Protection class auxiliary switch IEC/EN	II, reinforced insulation
	Degree of protection IEC/EN	IP54
	Degree of protection NEMA/UL	NEMA 2
	Enclosure	UL Enclosure Type 2
	EMC	CE according to 2014/30/EU
	Low voltage directive	CE according to 2014/35/EU
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14
	UL Approval	cULus according to UL60730-1A, UL60730-2-14 and CAN/CSA E60730-1
		The UL marking on the actuator depends on the production site, the device is UL-compliant in any case
	Type of action	Type 1
	Rated impulse voltage supply / control	0.8 kV
	Rated impulse voltage auxiliary switch	2.5 kV
	Pollution degree	3
	Ambient humidity	Max. 95% RH, non-condensing
	Ambient temperature	-3050°C [-22122°F]
	· ····································	



Technical data		
Safety da	ta Storage temperature	-4080°C [-40176°F]
	Servicing	maintenance-free
Weig	ht Weight	0.51 kg
Safety notes		
	 This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport. Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or aggressive gases interfere directly with the device and that it is ensured that the ambient conditions remain within the thresholds according to the data sheet at any time. Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation. The switch for changing the direction of rotation may only be operated by authorised specialists. The direction of rotation must not in particular be reversed in a frost protection circuit. The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user. Cables must not be removed from the device. The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed. 	
Product features	IND.	
Simple direct mountir		g on the ball valve with only one central screw. The assembly position indication. The mounting orientation in relation to 90° steps.
Manual overrio	de Manual override with push-but button is pressed or remains lo	ton possible (the gear train is disengaged for as long as the cked).
Adjustable angle of rotation	on Adjustable angle of rotation wit	h mechanical end stops.
High functional reliabili	ty The actuator is overload protec the end stop is reached.	ted, requires no limit switches and automatically stops when
Flexible signallir	ng With adjustable auxiliary switch	n (0100%)
	Auxiliary switch	
	1 1	



Accessories

Electrical accessories

Description	Туре	
Auxiliary switch 1x SPDT add-on	S1A	
Auxiliary switch 2x SPDT add-on	S2A	
Feedback potentiometer 140 Ω add-on	P140A	
Feedback potentiometer 1 k Ω add-on	P1000A	
Feedback potentiometer 10 k Ω add-on	P10000A	



Electrical installation




Supply from isolating transformer.


Parallel connection of other actuators possible. Observe the performance data. Direction of rotation switch is covered. Factory setting: Direction of rotation Y2.


Wire colours:


- 1 = black
- 2 = red
- 3 = white
- S1 = violet
- S2 = red S3 = white


Wiring diagrams












Auxiliary switch

Operating controls and indicators



Auxiliary switch settings



Note: Perform settings on the actuator only in deenergised state.

For the auxiliary switch position settings, carry out points 1 to 4 successively.

1 Manual override button

Holding button pressed down: Gear train disengages. Manual override is possible.

2 Shaft clamp

Turn until edge line \Lambda displays the desired switching position of the actuator and release button 1


3 Auxiliary switch

Turn rotary knob until the arrow points to the vertical line.

4 Cable


Connect continuity tester to S1 + S2 or to S1 + S3.

If the auxiliary switch should switch in the opposite direction, rotate the auxiliary switch by 180°.





Dimensions



Further documentation

- The complete product range for water applications
- Data sheets for ball valves
- Installation instructions for actuators and/or ball valves
- General notes for project planning